

12 Reclaim and Push Out Conditions

Not travel across operating, bridged or suspected bridged coal valves.

 Document Reference - MAC-CPP-PRO-011